

*Mar 30-20 made*  
*Apr 30/01- 10 made*  
*May 25/01- 7 "*  
*June 25/01- 8 "*  
*Sep 21/01- 11 "*  
*Nov 5/01- 7 "*  
*Jan 21/02 - 10 made*  
*Feb 27/02 - 10 "*  
*Mar 25/02 - 8 "*  
*May 7/02 - 11 "*  
*May 28/02 - 5 "*  
*July 31/02 - 10 "*  
*Oct 25/02 - 9 "*  
*Feb 6/03 - 8 "*  
*Apr 2 - 9 "*  
*May 2/03 - 7 "*  
*Aug 26 - 9 "*  
*Nov 4/03 - 6 "*

Date Purchased \_\_\_\_\_ Machine Serial No. \_\_\_\_\_

Size Of Spreader \_\_\_\_\_ Options \_\_\_\_\_

Please Note:

The Key Number System In This Parts Book Is Arranged As Follows:

- 0 -- Key Number With One Circle Denotes Main Assemblies
- Key Numbers Not Circled Are Individual Parts.


Please Order Parts By Number

**MODEL "E" TRUCK MOUNT  
12000, 14000, 15000, 18000 LITRE  
LIQUID MANURE SPREADER**

Operating And Safety Instruction:


1. After using spreader in freezing conditions make sure impeller housing is drained.
2. Wash tank inside and out each time work is finished. This will increase life of tank by many years.
3. Much of the fertilizer value of manure is lost when exposed to air. Getting the manure covered quickly is a very important part of spreading manure.
4. If rustproof coating on interior shows signs of deterioration, have interior repainted. This can be done with a roller or brush. This helps to increase the life of your spreader. It is a valuable maintenance procedure.
5. Make sure all moving parts are shielded to prevent coming in contact with loose clothing.
6. Never enter a tanker without special breathing equipment to supply oxygen. Manure gases can kill instantly. One breath of Hydrogen Sulphide can kill.

**18000 LITRE  
TRUCK MOUNT**



## 18000 L TM "E" TANK


<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	386-01-00-000	18000 L "E" Tank, Sill & Funnel Assy	1
2	340-01-01-000	18000L Tank Assy	1
3	316-22-00-000	Hold Down Bracket Assy	4
4	316-24-00-000	Hold Down Assy	4
5	364-47-00-000	Short Safety Bar Assy	2
6	364-49-00-000	Long Safety Bar Assy	1
7	340-01-01-300	Tank End	2
8	340-01-01-301	Tank Shell	3
9	340-01-01-302	Baffle	2
10	340-01-06-312	Tank End Stiffener	2
11	340-01-06-464	Stiffener Cap	4
12	340-01-01-557	Baffle Reinforcing Angle	4
13	340-62-00-553	Indicator	1
14	364-02-00-008	Ladder Rung	4
15	364-02-00-006	Manhole	1
16	300-01-00-012	Lift Hook	7
17	340-01-00-546	Reinforcing Plate	3
18	386-01-00-001	Vertical Reinforcing Channel	4
19	340-00-00-515	Sill	2
20	340-00-00-516	Sill Cap	4
21	384-00-00-106	Sill Rubber	2
22	340-01-00-498	Serial Number Plate	1
23	316-22-00-012	Hold Down Angle Bracket	4
24	316-22-00-035	Hold Down Angle Gusset	8
25	316-24-00-044	Bracket Main Piece	4
26	316-24-00-045	Spacer Bar	4
27	316-24-00-046	Hold Down Return	4
28	316-24-00-047	Gusset	8
29	364-00-00-155	Short Manhole Safety Bar	2
30	364-49-00-164	Long Manhole Safety Bar	1
31	340-62-00-000	Husky Flag Kit	1
32	340-00-00-536	Flag Spring Holder	1
33	R08152	#6 X 1/4" Pan Head Screw	2
34	R07663	1" X 3" Hex Head Bolt	2
35	R08246	1" Nyloc Hex Nut	4
36	R07669	1" X 8" Hex Hd Bolt	2
37	R08034	Hp88 1 X 4 Hold Down Spring	2
38	R09512	"Capacity" Decal	1
39	R09784	"Danger Toxic Gas" Decal	1
40	R09509	"Made In Canada" Decal	1
41	R09510	"Husky" Decal	2
42	R09511	Accent Strips	2
43	R09071	Serial Number	1
44	R07825	1/2" Flat Washer	3
45	R08207	5/32 X 1 1/2" S.S. Cotter Pin	3
46	R07828	1" Flat Washer	1
47	R08163	Clip	1
48	R08037	Flag Spring	1
49	R07926	5/16 - 18 X 1/4" S.S. Set Screw	1
50	R07803	3/8 Lock Washer	4
51	R07783	3/8" Hex Nut	4
52	364-95-00-000	Ladder Assy	1
53	364-95-00-324	Ladder Step	6
54	364-95-00-325	Ladder Side	2
55	364-95-00-326	Ladder Lug	2
56	364-95-00-327	Ladder Tank Lug	6
57	R07620	3/8 X 1 1/2 Hex Bolt	4
58	384-00-00-084	Sill Channel	3



## 15000L TM 'E' TANK

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	385-01-00-000	15000 L Tank,Sill & Funnel Assy	1
2	335-01-01-000	15000 L Tank Assy	1
3	364-47-00-000	Short Safety Bar Assy	2
4	364-49-00-000	Long Safety Bar Assy	1
5	340-62-00-000	Husky Flag Kit	1
6	316-22-00-000	Hold Down Bracket Assy	4
7	316-24-00-000	Hold Down Assy	4
8	335-01-01-002	15000 L Tank Shell	3
9	330-66-21-254	15000 L Tank End	2
10	330-66-00-257	Tank Stiffener	2
11	330-66-00-258	Stiffener Caps	4
12	300-01-00-012	Lift Hook	7
13	364-02-00-006	Manhole	1
14	333-26-00-049	Sills	2
15	332-11-00-026	Sill Caps	4
16	332-11-00-051	Vertical Reinforcing Channel	4
17	364-02-00-008	Ladder Rung	3
18	330-66-21-256	Baffle	1
19	330-66-21-570	Baffle Reinforcing Angle	2
20	340-62-00-553	Indicator	1
21	364-47-00-155	Manhole Safety Bar	2
22	364-49-00-164	Long Safety Bar	1
23	340-00-00-536	Flag Spring Holder	1
24	340-01-00-498	Serial Number Plate	1
25	316-22-00-012	Hold Down Angle Bracket	4
26	316-22-00-035	Hold Down Angle Gusset	8
27	316-24-00-044	Bracket Main Pc	4
28	316-24-00-045	Spacer Bar	4
29	316-24-00-046	Hold Down Return	4
30	316-24-00-047	Gusset	8
31	R07828	1" Flat Washer	4
32	R08207	3/32 X 1 1/2" S.S. Cotter Pin	3
33	R09071	Serial Number	1
34	R08152	#6 X 1/4" Pan Head Screw	2
35	R07663	1" X 3" Hex Head Bolt	2
36	R08246	1" Nyloc Hex Nut	4
37	R07669	1" X 8" Hex Head Bolt	2
38	R08034	H P 88 1 X 4" Hold Down Spring	2
39	R09509	"Made In Canada" Decal	1
40	R09512	"Capacity" Decal	1
41	R09784	"Danger Toxic Gas" Decals	1
42	R09510	"Husky" Decal	2
43	R09511	Accent Strip	2
44	R07783	3/8 Hex Nut	4
45	R08037	Flag Spring	1
46	R08163	Clip	2
47	R07926	5/16 - 18 X 1/4" S.S. Set Screw	1
48	R07803	3/8 Lock Washer	4
49	R07825	1/2" Flat Washer	3
50	R07620	3/8 X 1 1/2 Hex Bolt	4
51	364-95-00-000	Ladder Assy	1
52	364-95-00-324	Ladder Step	6
53	364-95-00-325	Ladder Side	2
54	364-95-00-326	Ladder Lug	2
55	364-95-00-327	Ladder - Tank Lug	6
56	384-00-00-084	Sill Channel	3
57	384-00-00-106	Sill Rubber	2


14000 LITRE



## 14000L TM 'E' TANK

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	384-01-00-000	14000 L Tank,Sill & Funnel Assy	1
2	330-66-21-000	14000 L Tank Assy	1
3	364-47-00-000	Short Safety Bar Assy	2
4	364-49-00-000	Long Safety Bar Assy	1
5	340-62-00-000	Husky Flag Kit	1
6	316-22-00-000	Hold Down Bracket Assy	4
7	316-24-00-000	Hold Down Assy	4
8	330-66-21-255	14000 L Tank Shell	3
9	330-66-21-254	14000 L Tank End	2
10	330-66-00-257	Tank Stiffener	2
11	330-66-00-258	Stiffener Caps	4
12	300-01-00-012	Lift Hook	7
13	364-02-00-006	Manhole	1
14	332-11-00-025	Sills	2
15	332-11-00-026	Sill Caps	4
16	332-11-00-051	Vertical Reinforcing Channel	4
17	364-02-00-008	Ladder Rung	3
18	330-66-21-256	Baffle	1
19	330-66-21-570	Baffle Reinforcing Angle	2
20	340-62-00-553	Indicator	1
21	364-47-00-155	Manhole Safety Bar	2
22	364-49-00-164	Long Safety Bar	1
23	340-00-00-536	Flag Spring Holder	1
24	340-01-00-498	Serial Number Plate	1
25	316-22-00-012	Hold Down Angle Bracket	4
26	316-22-00-035	Hold Down Angle Gusset	8
27	316-24-00-044	Bracket Main Pc	4
28	316-24-00-045	Spacer Bar	4
29	316-24-00-046	Hold Down Return	4
30	316-24-00-047	Gusset	8
31	R07828	1" Flat Washer	4
32	R08207	3/32 X 1 1/2" S.S. Cotter Pin	3
33	R09071	Serial Number	1
34	R08152	#6 X 1/4" Pan Head Screw	2
35	R07663	1" X 3" Hex Hd Bolt	2
36	R08246	1" Nyloc Hex Nut	4
37	R07669	1" X 8" Hex Hd Bolt	2
38	R08034	Hp88 1 X 4" Hold Down Spring	2
39	R09509	"Made In Canada" Decal	1
40	R09512	"Capacity" Decal	1
41	R09784	"Danger Toxic Gas" Decal	1
42	R09510	"Husky" Decal	2
43	R09511	Accent Strip	2
44	R07783	3/8 Hex Nut	4
45	R08037	Flag Spring	1
46	R08063	Clip	2
47	R07926	5/16 - 18 X 1/4" S.S. Set Screw	1
48	R07803	3/8 Lock Washer	4
49	R07825	1/2" Flat Washer	3
50	R07620	3/8" X 1 1/2 Hex Bolt	4
51	364-95-00-000	Ladder Assy	1
52	364-95-00-324	Ladder Step	6
53	364-95-00-325	Ladder Side	2
54	364-95-00-326	Ladder Lug	2
55	364-96-00-327	Ladder - Tank Lug	6
56	384-00-00-084	Sill Channel	2
57	384-00-00-106	Sill Rubber	2

12000 LITRE





## 12000L TM 'E' TANK


<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	383-01-00-000	12000L Tank, Sill & Funnel Assy.	1
2	326-88-25-000	12000L Tank Assy.	1
3	364-47-00-000	Short Safety Bar Assy.	2
4	364-49-00-000	Long Safety Bar Assy.	1
5	340-62-00-000	Husky Flag Kit	1
6	316-22-00-000	Hold Down Bracket Assy.	4
7	316-24-00-000	Hold Down Assy.	4
8	326-88-25-278	12000L Tank Shell	3
9	326-88-25-277	12000L Tank End	2
10	326-88-00-280	Tank Stiffener	2
11	330-66-00-258	Stiffener Caps	4
12	330-01-00-012	Lift Hook	7
13	364-02-00-006	Manhole	1
14	327-15-00-027	Sills	2
15	327-15-00-028	Sill Caps	4
16	327-15-00-050	Vertical Reinforcing Channel	4
17	364-02-00-008	Ladder Rung	7
18	326-88-25-279	Baffle	1
19	326-88-25-571	Baffle Reinforcing Angle	2
20	340-62-00-553	Indicator	1
21	364-47-00-155	Manhole Safety Bar	2
22	364-49-00-164	Long Safety Bar	1
23	340-00-00-536	Flag Spring Holder	1
24	340-01-00-498	Serial Number Plate	1
25	316-22-00-012	Hold Down Angle Bracket	4
26	316-22-00-035	Hold Down Angle Gusset	8
27	316-24-00-044	Bracket Main Pc	4
28	316-24-00-045	Spacer Bar	4
29	316-24-00-046	Hold Down Return	4
30	316-24-00-047	Gusset	8
31	R07828	1" Flat Washer	4
32	R08207	3/32 X 1 1/2" Ss Cotter Pin	3
33	R09071	Serial Number	1
34	R08152	#6 X 1/4" Pan Head Screw	2
35	R07663	1" X 3" Hex Hd Bolt	2
36	R08246	1" Nyloc Hex Nut	4
37	R07669	1" X 8" Hex Hd Bolt	2
38	R08034	Hp88 1 X 4" Hold Down Spring	2
39	R09509	"Made In Canada" Decal	1
40	R09512	"Capacity" Decal	1
41	R09784	"Danger Toxic Gas" Decal	1
42	R09510	"Husky" Decal	2
43	R09511	Accent Strip	2
44	R07783	3/8 Hex Nut	4
45	R08037	Flag Spring	1
46	R08063	Clip	2
47	R07926	5/16 - 18 X 1/4" Ss Set Screw	1
48	R07803	3/8 Lock Washer	4
49	R07825	1/2" Flat Washer	3
50	R07620	3/8 X 1 1/2 Hex Bolt	4
51	364-95-00-000	Ladder Assy.	1
52	364-95-00-324	Ladder Step	6
53	364-95-00-325	Ladder Side	2
54	364-95-00-326	Ladder Lug	2
55	364-95-00-327	Ladder - Tank Lug	6
56	384-00-00-084	Sill Channel	3
57	384-00-00-106	Sill Rubber	2

FAN & HOUSING KIT

<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	364-81-00-000	Fan & Housing Assy Complete	1
2	364-81-01-000	Fan Housing W/O Flange	1
3	364-81-02-000	Housing Inlet Flange Assy	1
4	364-41-00-000	P T O Holder Assy	1
5	364-62-00-000	Drain Plug Kit	1
6	364-31-00-000	Hose Tube Assy "6"	1
7	358-92-01-000	Hose Tube Assy "8"	1
8	364-82-00-000	Flanged Tank Outlet Assy	1
9	364-65-00-000	540 Fan, Cover Plate & Bearing Kit	1
	364-66-00-000	1000 Fan, Cover Plate & Bearing Kit	1
10	364-67-00-000	Cover Plate Assy	1
11	364-61-00-000	Bearing Holder Assy	1
12	364-61-01-000	Bearing Holder Assy W/Caps	1
13	364-72-00-000	540 Fan Shaft & Agitator Assy	1
	364-73-00-000	1000 Fan Shaft & Agitator Assy	1
14	364-01-03-018	Housing Band	1
15	364-01-03-019	Housing Flange	1
16	364-01-03-106	Housing Back Plate	1
17	364-01-03-081	Fan Housing Vertical Pc	1
18	364-01-03-376	Discharge Ring - 6"	2
19	364-01-03-063	Discharge Tube	1
20	364-41-00-133	Pto Holder Bracket	1
21	364-41-00-132	Pto Holder	1
22	364-81-02-393	Flange	2
23	364-81-02-394	Inlet Extension	2
24	364-82-00-395	Rh Outlet Side Pc	1
25	364-82-00-396	Lh Outlet Side Pc	1
26	364-01-03-104	Outlet Top Pc	1
27	364-01-03-105	Outlet Bottom Pc	1
28	358-92-01-301	Discharge Ring	1
29	358-92-01-302	Discharge Tube	1
30	364-01-03-156	Housing Band Aid	1
31	364-00-00-029	Flip Guard	1
32	364-67-00-211	Cover Plate	1
33	364-61-00-192	Seal Tube Back Plate	1
34	364-61-00-197	R H Flip Guard Bracket	1
35	364-61-00-198	Lh Flip Guard Bracket	1
36	364-61-00-191	Bearing Tube	1
37	364-61-00-193	Seal Tube Gusset	2
38	364-00-00-332	Seal Tube Cap	1
39	364-72-00-226	Fan Shaft	1
40	364-63-00-209	Impeller Back Plate	1
41	364-63-00-208	540 R P M Fan Blade	4
	364-64-00-210	1000 R P M Fan Blade	4
42	364-03-00-024	Gusset	4
43	364-72-00-227	Agitator Blades	3
44	364-00-00-212	Stake Nut	1
45	R20238	Hardened Sleeve	1
46	R08175	5/16 - 18 U N C X 1 3/4 Cap Screw	2
47	R21196	Seal - 1.5 X 2.835 X .313	1
48	R20115	Cone	2
49	R20113	Cup	2


# FAN & HOUSING KIT CONTINUED

<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
50	R21197	Seal 2 1/2 X 3 X 1/4	3
51	R08188	1/4" N P T Grease Fitting	1
52	R09787	"Grease" Decal	1
53	R04100	Silicone Sealant	1
54	R07879	7/16" Flange Nut	4
55	R07774	7/16 X 1 1/4 Carriage Bolt Gr.5 Black	4
56	R07671	7/16 X 1 1/4 Hex Bolt	8
57	R07784	7/16 Hex Nut	8
58	R07804	7/16 Lock Washer	8
59	R09785	"Danger" Decal	1
60	R07619	3/8 X 1 Hex Bolt	7
61	R07886	3/8 Lock Nut	2
62	R07803	3/8 Lock Washer	5
63	R07783	3/8 Hex Nut	5
64	R07785	1/2" Hex Nut	16
65	R07664	1/2 X 1 1/4 Hex Bolt	16
66	R07805	1/2" Lock Washer	16




**DISCHARGE PIPE ASSEMBLY 9000L - 15000L**

<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	364-19-00-000	Discharge Pipe Assembly - 14000L	1
	359-30-00-000	Discharge Pipe Assembly - 15000L	1
	362-59-00-000	Discharge Pipe Assembly - 9000L & 12000L	1
	362-20-00-000	Discharge Pipe Assembly - 7000L	1
2	364-25-00-000	Discharge Pipe End Section	1
3	364-68-00-000	Splash Plate Assembly	1
4	357-16-00-000	6" Discharge Pipe Holder Kit	2
5	357-16-01-000	Base Holder Assy	2
6	357-16-02-000	Pipe Holder Assy	2
7	364-19-00-065	Horizontal Discharge Pipe 9000L, 12000L & 14000L	1
	359-30-00-108	Horizontal Discharge Pipe 15000L	1
	362-20-00-068	Horizontal Discharge Pipe 7000L	1
8	364-19-00-082	Discharge Pipe Corner Piece	2
9	364-19-00-064	Vertical Discharge Pipe 14000L & 15000L	1
	362-20-00-184	Vertical Discharge Pipe 7000L, 9000L & 12000L	1
10	364-19-00-087	Flange	2
11	364-25-00-088	Discharge Pipe Flange Piece	2
12	364-25-00-067	Discharge Pipe End Piece	1
13	364-68-00-215	Clamping Tube	1
14	364-21-00-071	Clamping Tube Bracket	2
15	364-21-00-069	Splash Plate	1
16	364-21-00-224	Splash Plate Wing	2
17	357-16-01-130	Base Plate	2
18	357-16-01-131	Stub	2
19	357-16-00-133	Pipe Holder - 6"	4
20	357-16-02-137	Upper Stub	2
21	364-00-00-066	Flex Hose	1
22	R07671	7/16 X 1 1/4 Hex Bolt	6
23	R07784	7/16 Hex Nut	6
24	R07804	7/16 Lock Washer	6
25	R07622	3/8 X 2 1/2 Hex Bolt	4
26	R07620	3/8 X 1 1/2 Hex Bolt	4
27	R07783	3/8 Hex Nuts	8
28	R07803	3/8" Lock Washer	8
29	R02482	6" Clamps	2



# 18000L DISCHARGE PIPE ASSEMBLY


<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	358-32-00-000	Discharge Pipe Assy - 18000L	1
2	364-25-00-000	Discharge Pipe End Section	1
3	364-68-00-000	Splash Plate Assy.	1
4	357-16-00-000	6" Discharge Pipe & Holder	2
5	357-16-01-000	Base Holder Assy.	2
6	357-16-02-000	Pipe Holder Assy	2
7	359-30-00-108	18000L Discharge Pipe - 6"	1
8	364-19-00-082	Discharge Pipe Corner Piece	2
9	358-32-00-109	Vertical Discharge Pipe	1
10	364-19-00-087	Flange	2
11	364-25-00-088	Discharge Pipe Flange Piece	1
12	364-25-00-067	Discharge Pipe End Piece	1
13	364-68-00-215	Clamping Tube	1
14	364-21-00-071	Clamping Tube Bracket	2
15	364-21-00-069	Splash Plate	1
16	364-21-00-224	Splash Plate Wing	2
17	357-16-01-130	Base Plate	2
18	357-16-01-131	Stub	2
19	357-16-00-133	Pipe Holder - 6"	4
20	357-16-02-137	Upper Stub	2
21	364-00-00-066	Flex Hose	1
22	R07671	7/16 X 1 1/4 Hex Bolt	6
23	R07784	7/16 Hex Nut	6
24	R07804	7/16 Lock Washer	6
25	R07622	3/8 X 2 1/2 Hex Bolt	4
26	R07620	3/8 X 1 1/2 Hex Bolt	4
27	R07783	3/8 Hex Nuts	8
28	R07803	3/8" Lock Washer	8
29	R02482	6" Clamps	2



## DRAIN PLUG KIT


<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	364-62-01-000	Drain Plug Sleeve Assy	1
2	364-62-04-370	Plug Washer	1
3	364-62-03-000	Handle Assy	1
4	364-62-00-199	Housing Brkt	2
5	364-62-01-200	Sleeve Linkage	1
6	364-62-01-201	Sleeve	1
7	R08316	1/2 X 3 1/2 Full Thread Car Bolt	1
8	364-62-02-203	Plug Plate	1
9	364-62-02-204	Plug Rubber	1
10	364-62-00-205	Short Linkage	1
11	364-62-03-206	Lh Handle	1
12	364-62-03-207	Rh Handle	1
13	364-01-03-110	Drain Pipe	1
14	R08176	1/4-20 Unc X 7/8 Short Thrd Bolt	4
15	R08048	1/4-20 Lock Nut	4
16	R07885	1/2-13 Unc Hex Nyloc Nut	1
17	R08046	1/2-13 Unc Jam Nut	3


### DRAIN PLUG KIT 364-62-00-000



## SITE GAUGE KIT

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	330-20-01-000	Float Arm Assy	1
2	330-20-02-000	Indicator Arm Assy	1
3	330-20-03-000	Access Tube Assy.	1
4	330-20-04-000	Cover Plate Assy	1
5	330-20-01-551	Float Arm	1
6	330-20-01-552	Float Straps	2
7	330-93-00-375	Float	1
8	330-20-04-562	Bronze Bearing Holder	1
9	330-20-02-553	Indicator Arm Hub	1
10	330-20-02-554	Indicator Arm	1
11	330-20-03-556	Access Tube	1
12	330-20-03-560	Access Tube Flange	1
13	330-20-00-557	Cover Plate	1
14	R20865	1/2 X 5/8 X 1/16" O Ring	1
15	R09529	"Full" Decal	1
16	R09530	"Empty" Decal	1
17	R07974	External Retaining Ring	2
18	R21173	1/2 X 5/8 X 1/2" Bronze Bushing	3
19	R08241	3/16 X 1 Stainless Steel Roll Pin	1
20	R07675	3/8 X 1 1/4" Hex Bolt	6
21	R07783	3/8" Hex Nut	6
22	R07803	3/8" Lock Washer	6
23	R08021	1/8 X 1 1/2" Stainless Steel Cotter Pin	1






MODEL "E" TRUCK MOUNT  
 DIRECT HYDRAULIC DRIVE KIT  
 384-02-00-000






## HYDRAULIC DIRECT DRIVE KIT

Item	Name	Description	Qty
1	384-02-01-000	DIRECT HYD DRIVE MT PLATE ASSY	1
2	R20883	60-18 COUPLING CHAIN	1
3	R21406	3/4" NPT PLASTIC PLUG	2
4	R21401	3/4" HEX COUPLING	2
5	R07911	3/8 X 3/4" SET SCREW	2
6	384-02-00-005	GUARD	1
7	R07744	1/2 X 2" CARRIAGE BOLT	4
8	R21422	MS160 HYDRAULIC MOTOR	1
9	R07805	1/2" LOCK WASHER	4
10	R07785	1/2" NC HEX NUT	4
11	R20815	7/8-14 SAE M X 3/4" ADAPTOR	1
12	R21332	3/4M X 3/4F NPT 90~ SWIVEL ADAPTER	1
13	384-02-00-007	60 B-18 SPROCKET FOR STR SHAFT	1
14	384-02-00-072	60 B-18 SPROCKET W/6 TOOTH SPLINE	1
15	R07698	1/4 X 1/2" HEX HEAD BOLT	6
16	R07801	1/4" LOCK WASHER	2
17	R20617	60-18 COUPLING COVER	1
18	384-02-05-000	HYDRAULIC HOSE ASSY-3/4"	2
19	R21393	3/4" HYDRAULIC TEE	2
20	R21202	3/4" NPT IN-LINE CHECK VALVE	1
21	R21308	7/16 SAE X 1/4 NPT ADAPTOR	1
22	384-02-00-008	HYDRAULIC HOSE CLAMP	1
23	R07620	3/8 X 1 1/2" HEX BOLT	4
24	R07783	3/8" NC HEX NUT	4
25	384-02-06-000	HYDRAULIC HOSE ASSY-3/4"	2
26	384-02-07-000	HYDRAULIC HOSE ASSY-DRAIN CASE	1
27	R21104	1/2 CLIP	4
28	R07781	1/4" NC HEX NUT	4
29	351-00-0-009	HYDRAULIC HOSE FASTENER	3
30	R21323	7/8 X 3/4" NPT SWV ADAPTOR	1



**ACCESSORIES**

<u>Keys</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	332-27-00-000	Taper Fender Kit-No Lights-8 Ft O A 14000 & 15000L	1
	327-29-00-000	Taper Fender Kit-No Lights-8Ft O A 12000L	
	386-02-00-000	Taper Fender Kit-No Lights-8' 6" O A 18000 & 23000L	
2	332-31-00-000	Taper Fender Kit W/Lights-8Ft O A 14000 & 15000L	1
	327-32-00-000	Taper Fender Kit W/Lights-8 Ft OA 12000L	
	386-03-00-000	Taper Fender Kit W/Lights-8' 6" O A 18000 & 23000L	
3	332-27-00-069	14000L & 15000L Fender End-No Lights R.H 8 Ft. OA	1
	332-27-00-070	14000L & 15000L Fender End-No Lights L.H 8Ft O A	1
	327-29-00-076	12000L Fender End-No Lights Rh 8Ft O A	1
	327-29-00-077	12000L Fender End-No Lights LH 8Ft OA	1
	386-02-00-013	18000L & 23000L Fender Ends-No Lights Rh 8' 6" O A	1
	386-02-00-014	18 & 23000L Fender Ends-No Lights L.H 8' 6"O A	1
4	332-27-00-054	14000 & 15000L Fender-8Ft OA	1
	327-29-00-061	12000L Fender-8 Ft O A	1
5	386-02-00-015	18000L & 23000L Fender-8' 6" O A	1
	332-31-00-071	R H Fender End W/Lights-8Ft O A 14000 & 15000L	1
	332-31-00-072	LH Fender End W/Lights-8Ft OA14000 & 15000L	1
	327-32-00-074	Rh Fender End W/Lights-8Ft O A 12000L	1
	327-32-00-075	Lh Fender End W/Lights-8Ft O A 12000L	1
	386-03-00-016	R H Fender End W/Lights-8' 6" O A 18 & 23000L	1
	386-03-00-017	LH Fender End W/Lights-8' 6" OA 18 & 23000L	1
6	332-27-00-056	14000 & 15000L Front End Plate L H	1
	332-27-00-053	14000 & 15000L Front End Plate R H	1
	327-29-00-062	12000L Front End Plate R H	1
	327-29-00-063	12000L Front End Plate LH	1
	386-02-00-018	18000 & 23000L Front End Plate R H	1
7	386-02-00-019	18000 & 23000L Front End Plate L H	1
	332-27-00-055	14000 & 15000L Fender Gusset	2
	327-29-00-064	12000L Fender Gusset	2
	386-02-00-020	18000 & 23000L Fender Gusset	2
8	332-31-00-073	Inside Light Cover	2
9	372-00-00-032	Mudflap Clamp Strap	2
10	372-00-00-045	Sticker Plate	1
11	372-00-00-046	Sticker Plate Bracket	2
12	R09528	Mud Flap	2
13	R10192	Aluminium Junction Box W/Lid	1
14	R10193	Water Tight Connectors	-
15	R04060	1/2" Plastic Tube	-
16	R21082	Hose Clips	-
17	R10091	3 Cluster Clearance Light	1
18	R10093	Licence Plate Light	1
19	R10087	4" Stop & Tail Light	4
20	R10088	4" Clear Backup Light	2
21	R10089	Red Clearance Light	2
22	R10090	Amber Clearance Light	2
23	R09502	Husky Decal	
24	R10361	Reflective Tape	



ADDITIONAL PARTS INCLUDED IN KIT  
 384-06-11-000 HYD HOSE ASSY 2 PCS  
 384-06-12-000 HYD HOSE ASSY 1 PC  
 384-06-13-000 HYD HOSE ASSY 1 PC  
 384-06-14-000 HYD HOSE ASSY 1 PC  
 384-06-15-000 HYD HOSE ASSY 1 PC  
 290-00-00-167 HYD HOSE CLIPS AS NEEDED  
 RESTRICTORS, ELBOWS, BUSHINGS  
 AND ALL NUTS AND BOLTS.

<b>HUSKY HUSKY FARM EQUIPMENT LTD</b>	
<b>TRUCK MOUNT SPREADER</b>	SCALE: <b>KS</b>
DESC: 6' SWING BOOM KIT V/SPLASH PLATE	DRAWN BY: <b>KS</b>
MAT'L:	DATE: <b>NOV 22/2000</b>
QTY: <b>1</b>	SIZE: <b>R</b>
<b>384-06-00-000</b>	


SEE ADDITIONAL PAGE FOR PART DESCRIPTION

NOTE: KIT IS FOR 14000 AND 15000 LITER TANK PROFILES



## 6" SWING BOOM KIT W/SPLASH PLATE

Item	Name	Description	Qty
1	384-06-01-000	HOUSING TO VALVE CONN ASSY	1
2	384-06-03-000	CROSS PIPE ASSY	1
3	384-06-18-000	SADDLE ASSY 6"	1
4	384-06-02-000	VERTICAL DISCHARGE PIPE ASSY	1
5	384-05-01-000	DOUBLE SEAL HOLDER ASSY	1
6	384-05-03-000	DISCHARGE SUPPORT ASSY-6"	1
7	384-06-06-000	BOOM VERTICAL SUPPORT ASSY	1
8	384-05-04-000	CLAMP ASSY	1
9	364-25-00-000	DISCHARGE PIPE END SECTION	1
10	364-68-00-000	SPLASH PLATE ASSY	1
12	384-06-22-000	BOOM ASSY COMPL W/SNORKEL	1
11	384-06-09-000	INNER BOOM HOLDER ASSY	1
15	384-06-17-000	OUTER BOOM HOLDER ASSY	1
13	384-06-16-000	DRIP FUNNEL ASSY	1
14	384-06-19-000	CYLINDER BRKT ASSY	1
16	R20732	2 X 20" HYDRAULIC CYLINDER	1
17	R20725	2 X 8" HYDRAULIC CYLINDER	1
18	364-58-00-000	6" FLAPPER VALVE COMPL W/CYLINDER	1

**HUSKY** HUSKY FARM EQUIPMENT LTD  
**TRUCK MOUNT SPREADER**  
 SCALE: DRAWN BY: KS  
 DESC: 8' SWING BODY KIT W/SPLASH PLATE DATE: NOV 22/2000  
 MAT'L: QTY: 1 SIZE: R  
 385-05-00-000



- ADDITIONAL PARTS INCLUDED IN KIT  
 384-06-11-000 HYD HOSE ASSY 2 PCS  
 384-06-12-000 HYD HOSE ASSY 1 PC  
 384-06-13-000 HYD HOSE ASSY 1 PC  
 384-06-14-000 HYD HOSE ASSY 1 PC  
 384-06-15-000 HYD HOSE ASSY 1 PC  
 290-00-00-167 HYD HOSE CLIPS AS NEEDED  
 RESTRICTORS, ELBOWS, BUSHINGS  
 AND ALL NUTS AND BOLTS.



SEE ADDITIONAL PAGE FOR PARTS DESCRIPTION

NOTE: KIT IS FOR 14000 AND 15000 LITER TANK PROFILES

REVISION: DATE:

## 8" SWING BOOM KIT W/SPLASH PLATE

Item	Name	Description	Qty
1	386-05-04-000	8" CROSS PIPE ASSY	1
2	386-08-00-000	8" DRIP FUNNEL ASSY	1
3	386-05-10-000	8" DOUBLE SEAL HOLDER ASSY	1
4	385-05-08-000	8" BOOM VERTICAL SUPPORT ASSY	1
5	385-05-07-000	8" INNER BOOM HOLDER ASSY	1
6	385-05-09-000	8" VERTICAL DISCHARGE PIPE ASSY	1
7	358-92-03-000	8" EXTENSION PIPE ASSY	1
8	385-05-06-000	8" OUTER BOOM HOLDER	1
9	358-92-04-000	8" SPLASH PLATE ASSY	1
10	386-05-11-000	8" CLAMP ASSY	1
11	385-05-04-000	8" VERTICAL DISCHARGE PIPE HOLDER ASSY	1
12	R20725	2 X 8" HYDRAULIC CYLINDER	1
13	R20732	2 X 20" HYDRAULIC CYLINDER	1
14	384-06-19-000	CYLINDER BRKT ASSY	1
15	364-58-08-000	CYLINDER AND BRKT KIT	1
16	385-05-10-000	8" BOOM ASSY COMPL W/SNORKEL	1
17	386-05-12-000	8" SADDLE ASSY	1
18	385-05-03-000	HOUSING TO VALVE CONN ASSY-8"	1
19	386-07-00-000	8" FLAPPER BOX LESS HYD CYLINDER	1

## ELECTRIC HYDRAULIC UNIT

<u>Key</u>	<u>Parts Number</u>	<u>Description</u>	<u>Qty</u>
1	R21424	M-130 1 Valve Electric/Hydraulic Unit	1
	R21427	M-380 2 Valve Electric/Hydraulic Unit	*
2	R04056	4 Ga. Battery Cable-Live	3M
3	R04056	4 Ga. Battery Cable-Ground	1M
4	R04063	Copper Wire End For Cable	4
5	R21334	1/4" M X 3/8 F 90 Sw Fitting	2
6	R11114	Hydraulic Hoses - As Needed	-

### 372-10-00-000 ELECTRIC HYDRAULIC UNIT

